

Philibert De l'Orme,  
LES LIVRES D'ARCHITECTURE

Modern vaults, the master masons were accustomed  
to churches and homes of the nobles.  
CHAPTER VIII.

The master builders of this kingdom, and also other countries  
are accustomed to the vaults of churches esuela is great space  
(as are large rooms) with a cross they call ribbed. After you are  
well aware of the names and parts of the vault which I propose  
below, you will recognize his rise consecutively to circular lines  
described above the plane of said vault, as also that of warheads  
marked O, tiercerons marked T, arches and signed doubleaux E,  
and L walings signed, as you can and find out with the compass,  
always taking the branch length on the plan and starting at the  
corners, and from F to A, for half the length of the nose which  
is diagonal, depending on which one makes the climb, and so  
the other parties, which must be sought by same way.

